Copyright 1919. By A. I. E. E.

ABNORMAL VOLTAGES WITHIN TRANSFORMERS

BY L. F. BLUME AND A. BOYAJIAN

ABSTRACT OF PAPER

Mathematical analysis is made of a rectangular wave impinging upon a transformer winding and quantitative values deduced of the resulting internal voltage stresses in terms of transformer constants. It is shown that the conclusions also apply in part to abrupt impulses and approximate idea is given of the reaction of a transformer to high frequencies. The difference between operating transformer with isolated and grounded neutral is shown. Energy losses are not considered in the mathematics although the manner in which the results are affected is pointed out. Finally, theoretical results are compared with impulse and high-frequency tests made in the laboratory.

I.—Introduction

To avoid breakdown of transformers resulting from abnormal voltages, the present practise is to either safeguard the transformer winding by external protective devices which are designed to prevent line disturbances from reaching the transformer, or to insulate the windings to withstand them. A third but less obvious method is so to design the transformer that voltage disturbances entering the winding will not result in excessive voltage concentration.

By showing in what way the transformer constants influence the voltage concentration this paper indicates how a transformer may be so designed as to mitigate the stresses occasioned by a given voltage disturbance.

II.—Conclusions

Theory and experiment both of which are fully described later in the paper confirm the following conclusions.

- 1. Transformers differ from transmission lines on account of the presence of coil-to-coil capacitance and mutual inductance.
 - 2. Three kinds of disturbances are recognized:
 - A—abrupt impulses: B—rectangular waves with long tails: C—high-frequency voltages sustained and damped.



A. ABRUPT IMPULSES

- 3. The presence of coil capacitance causes the transformer to respond as a capacitance and not as an inductance to abrupt impulses and towards all frequencies* above its lower natural frequencies of oscillations.
- 4. The voltage distribution within the transformer windings for abrupt impulses and for high frequencies depends upon the factor.

$$\alpha = \sqrt{\frac{C_{\theta}}{C_{\bullet}}}$$

where C_{σ} is the total capacitance of winding to ground and C_{\bullet} is the total coil capacitance from one end of the coil stack to the other.

- 5. The greater the value of alpha, the greater the concentration of voltage at the line end and the smaller the voltage in the interior of the winding. The maximum volts per unit length of coil stack at the line end is equal to alpha times the value of the voltage corresponding to uniform distribution. In high-voltage power transformers of disk high-voltage, and concentric-barrel low-voltage windings, the value of alpha varies from 5 to 30.
- 6. The more abrupt the impressed impulses, or the higher the impressed frequency, the greater is the concentration of voltage at the line ends. The maximum voltage expressed in the preceding paragraph corresponds to a perpendicular wave front or infinite frequency impressed.
- 7. If the turns are uniformly distributed throughout the windings, alpha is also the factor giving the concentration of the volts per turn at the line end; but on account of extra turn insulation, the usual practise is to considerably reduce the number of turns on the end coils.

As the voltage concentration in the end coils depends upon the value of series and ground capacitances and is independent of the number of turns, it follows that the volts per turn on the end turns is inversely as the number of turns per coil. For this reason it is evident that extra turn insulation will be effective only when it is so designed that the increase in dielectric strength is greater than the increase in voltage concentration.

8. For abrupt impulses and for very high-frequency



^{*}See paragraph 15.

oscillations it is immaterial whether the neutral is isolated or grounded.

B. RECTANGULAR WAVES WITH LONG TAILS

- 9. If the impulse has a long tail, the phenomena within the transformer will be initially as described in paragraphs 1 to 5 above, followed by a series of damped oscillations, the amplitudes of these oscillations depending not only on the amplitude of the impressed wave but also on the value of alpha, and on whether the neutral is isolated or grounded.
- 10. In addition to being proportional to the value of the impressed wave the amplitude of oscillation for a given harmonic is smaller the higher the harmonic and the smaller the value of alpha.
- 11. There is no simple relation between wave length and frequency and on that account waves cannot penetrate into a transformer winding without distortion.
- 12. As these oscillations occur simultaneously within the transformer windings, the resultant voltage distribution at any instant is obtained by re-combining the harmonics at that instant.
- 13. For isolated neutral and for alpha equal to 10, a maximum of 2.8 times impressed volts exists from neutral to ground and the volts per turn in the interior of the windings is approximately four times normal.
- 14. For grounded neutral and for alpha equal to 10, a maximum of 1.5 times impressed volts exists from the windings to ground, and the volts per turn in the interior of the windings are increased to four times normal and at the neutral to 7.5 times normal.

C. HIGH FREQUENCY

- 15. When the applied high frequency is greater than the natural frequency of the transformer, the reaction of the transformer is similar to its reaction towards abrupt impulses, and paragraphs 3 to 8 apply.
- 16. Theoretically, by impressing a sustained high-frequency voltage across transformer terminals at a natural oscillating frequency of the windings, the transformer can be made to resonate and indefinite voltages built up limited only by internal losses. However, if the transformer is excited by a transmission line, the voltage built up by resonance is also

limited by the relative values of surge impedance of transformer and line.


- 17. However in the high frequency tests here reported extreme high voltages were not observed. This is probably due to the following reasons:
 - (a) The impressed high-frequency was highly damped.
 - (b) The presence of internal capacitances shunting the windings decreases the rapidity with which the voltage is accumulated.
 - (c) Internal losses within the transformer windings.
- 18. The effects of (b) and (c) are greater the higher the frequency of oscillation. For this reason high internal voltages are built up, only at the lower frequencies.

III.—Description of Phenomena

The theory of electrical waves in transmission lines cannot be directly applied to transformers due to the fact that a transformer, unlike a transmission line,

possesses capacitance between coils and mutual inductance.

Assuming that the inductance and capacitances are uniformally distributed along the winding as diagrammatically represented in Fig. 1, mathematical analysis can readily be



applied, but if the constants are bunched as is the case for transformers in which the high and low voltage windings are interlaced, the problem becomes very complicated.

A good example of a concentric winding transformer to which the conclusions of this report are applicable is given in Fig. 4. This is a three-phase 2500-kv-a. transformer, the 100,000-volt winding of which is Y connected and made up of three stacks of disk coils. It is necessary to assume that the capacitances between turns and layers are very large compared with capacitances between coils and ground to make Fig. 1 applicable.

The purpose of this paper is to show what takes place within the transformer windings under the impact of rectangular waves. Rectangular waves are chosen rather than periodic waves on account of the greater simplicity of the problem, and

^{*}See Abnormal Voltages on Transformers, by J. M. Weed, A. I. E. E. Trans. 1915, p. 1621.

waves of long duration (long compared with the time of a complete oscillation within the transformer) are assumed because the resulting voltages are greater than with the very short waves or impulses.

In general there will be two cases requiring separate treatment depending upon whether the neutral is isolated or grounded.

Although the phenomena with which we are dealing involves in its entirety only a very small fraction of a second, it is nevertheless convenient to divide it into three distinct time periods, each requiring separate treatment. These will be designated; 1, initial period; 2, transient period; 3, final period.*

The initial period is the period from the beginning of the disturbance to the time of maximum applied voltage. The time involved is so small that there is no appreciable growth of magnetic flux and therefore the phenomena may be considered entirely electrostatic without appreciable error. This is followed by a transient period during which there is a continual interchange of energy between the electric and magnetic fields. The energy interchange usually takes the form of highly damped high-frequency voltage and current oscillations. When the oscillations become negligible the final period has been reached in which the winding has again assumed a permanent condition of equilibrium.

TRANSFORMER REACTING AS A CONDENSER

Due to the combination of coil and ground capacitances, the transformer, during the initial period, reacts as a concentrated capacitance. The condensers are rapidly charged and the voltage across them rises to nearly double the voltage of the incoming wave. The time required for charging is so very small that it is safe to assume that twice the voltage of the incoming wave is applied to the terminals of the transformer windings before an appreciable inductive current can be established in the windings. The equivalent or effective capacitance of the transformer, while being charged, is approximately given by equation (21),

$$C_{eff} = \sqrt{C_{\bullet} \times C_{\bullet}} \tag{21}$$

where C_{σ} is the total capacitance of the surface of transformer

^{*}See paper by Karl Willy Wagner entitled "Progress of Waves in Windings." Elektrotechnik und Maschinenbau." Feb. 21, and 28th, 1915.

winding to ground, C_{\bullet} is the capacitance between the two ends of the winding. The calculation of the latter capacitance is simplified by assuming that the ends of the winding are electrically connected to clamping plates or end rings. C_{\bullet} is then defined as the capacitance between these plates.

INITIAL VOLTAGE DISTRIBUTION

The voltage distribution throughout the transformer winding when the condensers are charged is given by formula (11b) for isolated neutral, and formula (13b) for grounded neutral.




Fig. 2—Neutral Isolated

Fig. 3—Neutral Grounded


$$e = E_0 \frac{\cosh \frac{\alpha x}{l}}{\cosh \alpha}$$
 (11b)

$$e = E_0 \frac{\sinh \frac{\alpha x}{l}}{\sinh \alpha}$$
 (13b)

where E_0 is value of voltage to ground on the transformer terminals. This will be either twice the value of the incoming wave, or, if lightning arresters are assumed, the maximum voltage permitted by the protective device.

The value of alpha is the square root of the ratio of the ground capacitance (C_a) to coil capacitance (C_a) .

Plotting the ratio e/E_0 as ordinate and the ratio x/l as abscissa gives the system of curves shown in Figs. 2 and 3. For alpha equals zero, that is, ground capacitance zero, the curve is a straight line (uniform voltage distribution). The



[BLUME AND BOYAJIAN]

Fig. 4—Three-Phase—60-Cycle—2500 Kv-a.—100,000-Volt Transformer

greater the value of alpha the less uniform becomes the voltage distribution and the more is the voltage concentrated at the end of the winding. This is the reason for the modern practise of putting extra insulation on the coils and turns at the line ends.

It should be noted that these curves are based on windings in which the turns are uniformly distributed along the coil stack. On account of the space required by the extra end turn insulation it follows that there are fewer turns per unit length of coil stack at the ends of the windings. The effect of this is to cause a still greater concentration of voltage at the ends.

FINAL VALUE OF VOLTAGE DISTRIBUTION

- (a) Eventually, in case of isolated neutral, the voltage of the winding will be brought to a potential of twice the original value of the wave with zero current flowing.
- (b) For the case of grounded neutral the final condition will be a straight line with neutral at ground potential and line at twice the voltage of the original wave, with a current in the winding increasing at a constant rate, (assuming no resistance).

TRANSIENT VOLTAGE DISTRIBUTION

The transient by which the voltage distribution changes from the initial to the final value can be analyzed into a complex series of damped oscillations or standing waves at various frequencies, wave lengths and damping factors.

The maximum values of these standing waves are readily obtained by analyzing the initial voltage distribution as given in curves, Fig. 2, into space harmonics with respect to the final voltage distribution as axis of reference. Thus we have for $\alpha = 10$ the following initial values of the standing waves.

NEUTRAL ISOLATED		NEUTRAL GROUNDED.		
Wave length on winding	Amplitude in percent of line to ground voltage En/E	Wave length on winding.	Amplitude in per cent of line to ground voltage e/E_0	
1/4	. 125%	1/2	58%	
3/4	34%	3/2	23%	
5/4	15%	5/2	6%	
7/4	7%	7/2	4%	
9/4	3%	9/2	3%	



These oscillations at various frequencies occur simultaneously within the transformer windings and the complex wave at a given time is obtained by recombining the harmonics at that time (Fig. 5).

The equation of any standing wave in a transformer winding. is

$$e_{z} = E_{n} \operatorname{Sin} \left(2 \pi n \frac{x}{l} \right) \cos w_{n} t$$
or
$$e_{z} = E_{n} \operatorname{Cos} \left(2 \pi n \frac{x}{l} \right) \cos w_{n} t$$
(33d)




Fig. 5—Voltage Distribution within Transformer Windings at Various Times after Impact of Rectangular Wave

where n is the number of wave lengths per harmonic along the stack. For the fundamental, n is $\frac{1}{2}$ when neutral is grounded, and $\frac{1}{4}$ when neutral is isolated. The frequency of oscillation is given by the equation:

$$f = \frac{2 \pi n^2}{\sqrt{L (C_a + 4 \pi^2 n^2 C_A)}}$$
 (35e)

These equations are particular solutions of the general differential equations and are derived under the heading of "Mathematical Development." An inspection of formula (35e) shows that the natural frequencies are a function of the wave lengths. For $\alpha = 10$ the variation of wave lengths with frequency is as follows:

NEUTRAL ISOLATED		NEUTRAL GROUNDED	
Wave length	Relative * frequencies	Wave length	Relative frequencies
n		*	,
1/4	1	1/2	4
3/4	8	2/2	14
5/4	20	3/2	28
7/4	33	4/2	42
9/3	47	5/2	56

^{*}These figures are not accurate due to the variation of inductance with wave length as discussed on another page.

This peculiar relation between frequency and wave length is due to the presence of coil capacitance and mutual inductance, and causes a continual change in the form of the complex wave from instant to instant. This is in marked contrast to the phenomena which take place in the transmission line, where a complex wave of any shape will be propagated without distortion, except for the effect of resistance.

MAXIMUM VOLTAGE TO GROUND AND MAXIMUM VOLTS PER TURN

The considerations of greatest interest in connection with these curves are the maximum voltages to ground and the maximum volts per turn at various points within windings. These are plotted in Figs. 6 and 7. Of course the maximum values of voltages at the various points do not occur at the same instant.

An inspection of these curves shows that, for the case of isolated neutral, the maximum voltage to ground occurs at the neutral and is equal to 2.8 times the voltage from line to ground and for grounded neutral the maximum volts to ground is 1.5 times line to ground voltage. The volts per turn for isolated neutral is 10 times normal at line end, 4 times normal in the major portion of winding, and zero at the neutral. With neutral grounded it is 10 times normal at line end 5 times nor-

mal in the major portion of the winding and 7.5 times normal at the neutral.

SURGE IMPEDANCE

In order to have a convenient means of calculating the maximum value of current associated with each oscillation the ratio of terminal volts to maximum current is given by

$$Z = \frac{E}{I} = \frac{1}{2 \pi n} \sqrt{\frac{L}{C_g + 4 \pi^2 n^2 C_\bullet}}$$
 (39b)

The value of surge impedance calculated for the transformer shown in Fig. 4 is 60,000 for the fundamental, 29,000 for the




Fig. 6—Voltage Distribution within Transformer Windings
Maximum Values after Impact of Rectangular Waves

third harmonic, 17,000 for the fifth harmonic and 12,000 for the seventh harmonic.

In the analysis just given it has been tacitly assumed that the voltage E applied across the terminals of the transformer winding is maintained throughout the oscillations. Strictly speaking, this is not true, because during the time when the voltage to ground is increasing in the interior of the winding, the transmission line is delivering current to the transformer windings, and during the time when this voltage to ground is decreasing, the transmission line is receiving current from the transformer windings, or in other words, there is a continual interchange of energy between the transmission line and the

winding throughout the oscillation, and as the ratio of voltage to current associated in the rectangular wave in the transmission line is a constant value, this interchange of energy cannot take place without modifying the line voltage. However, calculations of equivalent surge impedance show that in all practical transformers the amount of energy absorbed and delivered by the transformer windings is very small compared with the energy residing in the rectangular wave, and that, therefore, this fluctuation in voltage is negligible in amount.

Again it may at first appear that the axis of oscillation taken in the case of a grounded-neutral transformer, cannot be correct




Fig. 7—Voltage Distribution within Transformer Windings Maximum Values after Impact of Rectangular Wave

because the final condition for the case of grounded neutral is zero voltage throughout the windings owing to the fact that the windings become a dead short circuit. This is again theoretically true but it has no bearing on the problem because in all practical cases the time taken for the transformer windings to degenerate into a short circuit is so very long compared with the time involved in the oscillation of the fundamental frequency that it can be safely assumed that the transformer winding oscillates through a complete cycle of the fundamental before the voltage applied to the terminals of the transformer windings can be appreciably lowered.

NATURAL FREQUENCY OF OSCILLATION OF A WINDING

Formula (35e) is useful for the purpose of obtaining the natural frequency of a winding. For a solenoid consisting of a single one-layer coil, the capacitance between turns may be neglected and the formula becomes.

$$f = \frac{2 \pi n^2}{\sqrt{L C_a}} \tag{35f}$$

From this equation we reach the very interesting conclusion that the natural frequency of oscillations are not simple multiples of the fundamentals in the order of 1, 2, 3, 4, etc., but that they are proportional to the square of these values that is 1, 4, 9, 16, etc., (neglecting the variation of inductance with wave length.)

If the capacitance between turns or coils is not negligible the formula reverts to equation (35e). The influence of coil capacitance is to make the natural frequencies lower than those given by formula (35f). Moreover, the harmonics are not simple multiples of the fundamental in every case.

At very high frequencies the influence of ground capacitance becomes negligible compared with series capacitance and the formula for frequency becomes,

$$f = \frac{n}{\sqrt{LC_s}} \tag{35g}$$

DAMPING FACTORS

Of course the voltage distribution as given in Fig. 5 departs considerably from what occurs in practise on account of dielectric losses, which introduce a damping factor, which is greater the higher the frequency.

It may be, therefore, especially where the order of frequencies progresses as the square of the wave lengths, that before the fundamental has completed one-half of a complete oscillation most of the higher frequencies have become negligible. A knowledge of the dielectric losses would be necessary to determine whether the voltage stresses are appreciably restricted by them.

HIGH-FREQUENCY TRANSIENTS

An idea of the transient phenomena occurring within a transformer winding when sustained high frequency is impressed

can best be obtained by considering the applied high frequency to be made up of successive positive and negative rectangular waves, the frequency of which is the same as the fundamental frequency of the transformer winding. During the time of the first half cycle, phenomena are as described above. When the applied wave changes from positive to negative, the voltage to ground within the transformer winding due to the fundamental has reached its maximum value. The effect of this change in applied voltage is to increase the amplitude of the fundamental approximately by twice the amplitude of the applied voltage. In the example given the above fundamental has a value of 1.24 times the terminal applied voltage for the case of isolated neutral. At each cycle this value is increased by twice the value of the terminal voltage, causing the voltage to ground to increase regularly in steps so that the maximum potential to ground at the end of the second half cycle is 4.72, at the end of the third half cycle 7.20 etc.

The above assumes that the internal losses are insufficient to reduce its amplitude and neglects the amplitude of all other harmonics. Of course, if the applied frequency happens to be equal to the frequency of one of the harmonics the building up of voltage by resonance as described above would apply to that harmonic and not to the fundamental.

It should be noted that the amplitude of the oscillations within the transformer winding are not necessarily the amplitude of the impressed voltage, but they depend upon the amplitude of impressed wave voltage and also upon the values given in the table under "Transient Voltage Distribution." These values are dependent upon the value of " α "; the smaller the value of " α " the smaller will be the value of internal oscillations, and moreover, for a given value of " α " the amplitudes of the oscillations are smaller for the shorter wave lengths.

However, when a sustained high frequency, or a damped oscillation, having a frequency equal to a natural frequency of the transformer, is impressed, the resulting stress as previously shown may very greatly exceed those given by the curves, the values being limited by the value of " α ", the internal losses, and the damping factor of the impressed wave. For a reliable quantitative analysis an accurate knowledge of all these factors is necessary.



IV.—Impulse Tests on Small High-Voltage Transformer Winding

A 30,000-volt transformer winding made up of a stack of 52 disk coils approximately 15 in. long and 10 in. in diameter was




Fig. 8—Impulse Tests on Small High-Voltage Transformer-Connection Diagram

used for these tests. Grounded metal cylinders were placed inside and outside of the stack, to simulate low-voltage winding and tank.




FIG. 9—IMPULSE TESTS ON SMALL HIGH-VOLTAGE TRANSFORMER—FOR CONNECTIONS SEE FIG. 8

Fig. 10—Impulse Tests on Small High-Voltage Transformer

The connection used in testing is shown in Fig. 8. Voltage was applied from line to ground; in some tests the neutral (one end) of the coil was grounded to the metal cylinders and in

the other test isolated. A spark gap A was connected in series with the coil, and a large condenser C in multiple with it. The operation is as follows: As the voltage rises, it charges the condenser C. This voltage also appears across the gap A, a very small part being consumed in the capacitance of the coil. When the gap arcs over, the entire voltage, abruptly applied across the winding, gives rise to a series of oscillations, within the winding. The use of the condenser C (which must be as large as practicable) is to maintain the applied voltage while the capacitance of the coil is being charged and also to allow an easy return path for the high-frequency oscillations set up




Fig. 11—High-Frequency Investigation—60 Cycles—3000 Kv-a.—140,000 Volts—Diagram of Connections

in the coil. As these oscillations die out before the 60-cycle voltage has appreciably changed, the impressed voltage is in effect a sustained rectangular wave.

The voltage to ground and the voltage gradients are plotted in Fig. 9 and Fig. 10.

Constants of the Coil

Ground capacitance $C_g = 12 \times 10^{-10}$ farads. Series capacitance $C_g = 4.4 \times 10^{-12}$ farads.

$$\alpha = \sqrt{\frac{C_o}{C_o}} = 16.5$$



V.—High-Frequency Tests*

High-frequency tests on the high-voltage windings of 3000-kv-a. 140,000-volt transformer (Fig. 4) compared with theoretically calculated stresses resulting from impact of rectangular waves.

Transformer constants:

 $C_{\rm g} = {\rm Ground\ capacitance} = 9 \times 10^{-10} {\rm\ farads}.$

 C_{\bullet} = Coil capacitance = 9×10^{-12} farads.

$$\alpha = \sqrt{\frac{C_{\theta}}{C_{\bullet}}} = 10$$

Connection diagrams for these tests are given in Fig. 11, and




Fig. 12—High-Frequency Voltages Measured between Taps

high-frequency voltages obtained across taps are plotted in Fig. 12 and Fig. 13. In Fig. 14 is plotted the approximate volts obtained by these tests at any frequency (curve marked by dots). For comparison the volts per turn as theoretically obtained for rectangular waves (See Fig. 6) and corrected for end turn insulation has been plotted on the same sheet (curve marked by crosses.) The theoretical values have been multiplied by two, for the following reason.

Discharge takes place every one-half wave at the maximum

^{*}Tests made by J. M. Weed and J. E. Clem.

point of the wave. Condensers discharge into the inductive circuit, the maximum value of high-frequency voltage being equal to maximum value of the 60-cycle voltage. One-half




Fig. 13—High-Frequency Voltages Measured between Taps

wave of the high-frequency discharge is shown in Fig. 15. It is seen that during this half cycle the high-frequency voltage changes from maximum positive to maximum negative. The original 60-cycle voltage distribution, just before the arc-over,




Fig. 14—3000-Kv-a.—140,000-Volt Transformer

is the straight line shown in Fig. 16. Half a high-frequency cycle after the arc-over, the resultant of the 60-cycle and high-frequency voltage distribution is shown by curve "a" in Fig. 16, assuming that the frequency is high enough for the wind-

ing to act as condenser for the first half cycle of the high-frequency wave. Thus it is evident that the combination of the high- and low-frequency waves doubles the voltage gradient.

Taps	Per cent turns	Per cent along stack	Maximum volts per tus times normal	
1—2 2—3	.19	2.1	147 at 1,500,000 Cycle 52 1,500,000 "	
3—4	4.	11.4	52 1,500,000 " 28 at 600,000 "	
3— <u>3</u> 4—5	8.2	16.7	25 at 000,000	
2 —3 5—6	13.5	22.5	11 at 62,000 " 13.5 at 900,000 "	
6—7	30.7	36	5.6 62,000 °	
7—8	48	51.5	11.5 62.000 4	
89	68	69	6 20,000 "	
9—10	89	86	9.9 62,000	
10-11	94	91.5	13 62,000 "	
11—12	98	97	14 62,000 "	

HIGH-FREQUENCY TEST DATA

The volts per turn occurring at ends of windings are the same as if a rectangular wave of voltage 2 E had been applied. For this reason the values for volts per turn as theoretically obtained for rectangular waves have been multiplied by two in order to




Fig. 15—Time-Voltage Curve at Line End of Winding

compare these values with the high-frequency test. The higher the frequency of test, the more nearly should the condenser volts per turn distribution equal twice the voltage distribution caused by a rectangular wave.

V-Mathematical Development

- 1. Initial voltage distribution in a winding for a steep wave front.
- 2. Initial effective or equivalent capacitance of a winding for a steep wave front.

- 3. Time required to charge the initial effective capacitance of a winding.
- 4. Analysis of transient phenomena following the initial. voltage distribution.
 - 5. Surge impedance of an oscillating winding.
 - 6. Example.




Fig. 16—Space-Voltage Curves for t=0 and $t=\frac{1}{2}$ High-Frequency Cycle

1. Initial Voltage Distribution in a Winding for Steep Wave Fronts

If voltage is suddenly applied to a system of inductances in multiple with a system of capacitances, the initial voltage distribution will be determined by the capacitances. At the




Fig. 17

instant of impact, the condensers short-circuit the steep wave front. If the wave is maintained, the condensers become charged, and the voltage rises. The time required for this charging is extremely small as given by equation (22). The voltage distribution, when the condensers are charged, is the same as that when an alternating voltage is applied to the system of condensers with the inductance disconnected. Considering the system of internal and ground capacitances by themselves (Fig. 17), and assuming an alternating voltage of

frequency f, $\left(f = \frac{\omega}{2\pi}\right)$, applied, the following relations will be evident.

Let C_{\bullet} = Capacitance between line end of coil and neutral, shunting the winding.

 C_o = Capacitance between winding and ground for a coil length of line to neutral.

l = Coil length line to neutral.

l C. = Capacitance between portions of winding unit distance apart.

 $\frac{C_g}{l}$ = Capacitance to ground per unit length of coil

e = Voltage to ground at any point.

 $\frac{d e}{d x}$ = Voltage gradient, volts per unit length of coil.

 E_0 = Impressed voltage line to ground.

 $\omega = 2 \pi f = \text{angular velocity.}$

 I_{\bullet} = Current in the coil capacitance C_{\bullet} .

$$= \omega C_{\bullet} l \frac{d e}{d x}$$
 (1)

 $I_{\sigma} = \text{Current in ground capacitance } C_{\sigma} \text{ (total.)}$

 $\frac{d I_g}{d x}$ = Current in ground capacitance per inch of coil.

$$= \omega \frac{C_{\mathfrak{g}}}{l} e \tag{2}$$

The increase per unit distance in the current of the shunt capacitance is the current supplied by the ground capacitance per unit length, that is,

$$\frac{dI_{\bullet}}{dx} = \frac{dI_{\bullet}}{dx} \tag{3}$$

Substituting in equation (3) the value of $\frac{dI_*}{dx}$ from (1), and

 $\frac{d I_g}{d x}$ from (2), and simplifying,

$$\frac{d^2 e}{d x^2} - \frac{1}{l^2} \frac{C_o}{C_*} e = 0 \tag{4}$$

The solution of this equation is of the form

$$e = A \epsilon^{px} \tag{5}$$

Substituting (5a) and its derivative in (4), and solving for p,

$$p = \pm \frac{1}{l} \sqrt{\frac{C_{g}}{C_{s}}}$$
 (6)

and

$$e = A \epsilon^{px} + B \epsilon^{-px} \tag{7}$$

The constants A and B are determined by the terminal conditions as follows.

Case I.—Neutral Isolated. If the neutral is isolated at x = 0 $I_* = 0$ (8)

The value of I_{\bullet} is, from (1) and (7).

$$I_{\bullet} = \omega \, l \, C_{\bullet} \, \frac{d \, e}{d \, x} \tag{9a}$$

$$= \omega l C_{\bullet} (A \epsilon^{px} - B \epsilon^{-px}). \tag{9b}$$

Substituting, x = 0, and $I_{\bullet} = 0$

$$0 = \omega l C_{\bullet} p (A - B)$$
 (10a)

$$A = B \tag{10b}$$

Substituting, (10b) in (7),

$$e = A \left(\epsilon^{px} + \epsilon^{-px} \right) \tag{10c}$$

$$= A' \cosh (p x)$$
 (10d)

Now, at
$$x = l$$
 $e = E_0$ (10e)

$$e = E_0 \frac{\cosh (p x)}{\cosh (p l)}$$
 (11a)

$$= E_0 \frac{\cosh\left(\frac{\alpha x}{l}\right)}{\cosh\left(\alpha\right)} \tag{11b}$$

where $\alpha = p l = \sqrt{\frac{C_{\theta}}{C_{\theta}}}$ and the neutral is isolated

Case II.—Neutral Grounded. The terminal conditions are

$$at x = 0 e = 0 (12a)$$

and at
$$x = l$$
 $e = E_0$ (12b)

Applying condition (12a) to equation (7).

$$0 = A + B$$

$$A = -B$$

$$e = A (\epsilon^{px} - \epsilon^{-px}).$$

$$e = A' \sinh p x$$
(12c)

Applying condition (12b) to equation (12d)

$$E_0 = A' \sinh p l \tag{12e}$$

$$A' = \frac{E_0}{\sinh p \, l}$$

Therefore,
$$e = E_0 \frac{\sinh p x}{\sinh p l}$$
 (13a)

$$= E_0 \frac{\sinh\left(\frac{\alpha x}{l}\right)}{\sinh\alpha} \qquad (13b)$$

where, $\alpha = p l = \sqrt{\frac{C_{\theta}}{C_{\bullet}}}$ and the neutral is grounded.

Initial voltage distribution curves for both the isolated neutral and the grounded neutral are given in Figs. 2 and 3.

GENERAL REMARKS ON THE INITIAL VOLTAGE DISTRIBUTION

When the capacitance to ground is negligible compared with the capacitance between coils, that is, $C_{\mathfrak{g}} = 0$, the initial voltage distribution is determined by the series capacitances and is a straight line if the capacitance between coils is uniform.

As the capacitance to ground more and more predominates, the curve becomes steeper near the line end, that is, the voltage is concentrated more and more near the line end.

The voltage gradient (volts per unit length) is $e_* = \frac{d e}{d x}$

$$= \frac{\alpha E_0 \sinh\left(\frac{\alpha x}{l}\right)}{l \cosh \alpha} \text{ neutral isolated}$$
 (14a)

$$= \alpha \frac{E_0}{l} \frac{\cosh\left(\frac{\alpha x}{l}\right)}{\sinh \alpha} \text{ neutral grounded}$$
 (14b)

The maximum voltage gradient is at the line end, x = l,

$$e_{\bullet} = \frac{\alpha E_{0} \sinh \alpha}{l \cosh \alpha}$$
 neutral isolated (15a)

=
$$\alpha \frac{E_0}{l} \tanh \alpha$$
 neutral isolated (15b)

Similarly
$$e_{\bullet} = \alpha \frac{E_0 \cosh \alpha}{l \sinh \alpha}$$
 neutral grounded (16a)

$$= \alpha \frac{E_0}{l} \coth \alpha \text{ neutral grounded}$$
 (16b)

For α greater than 3,

Tanh $\alpha = \coth \alpha = 1$

This is true for most transformers, and the voltage gradient at the line end becomes $\left(\frac{\alpha E_0}{l}\right)$ volts per unit length.

If the voltage were uniformally distributed throughout the winding, the gradient would have been $\left(\frac{E_0}{l}\right)$. Therefore,

when the total capacitance to ground is very much larger than the coil capacitance between neutral and line, the voltage gradient at the line end is α times the value corresponding to uniform distribution.

It will also be noticed that for values of α greater than 5, the initial voltage distribution for a steep wave front is practically the same for the case of isolated as for grounded neutral.

INITIAL EFFECTIVE CAPACITANCE OF A WINDING FOR A STEEP WAVE FRONT.

In calculating the time of charging the system of coil and ground capacitances by an incoming wave, it becomes necessary to know the effective capacitance of the combination, This is equal to the effective capacitance for alternating voltage.

Representing this effective capacitance by C_{eff} , line current by I, line voltage (a-c.) by E, frequency by "f".

$$I = 2 \pi \dot{f} C_{eff} E \qquad (17a)$$

or
$$C_{\text{eff}} = \frac{I}{2 \pi f E}$$
 (17b)

But
$$I = I_{\bullet}$$
 at $x = l$ (17c)

and
$$I_{\bullet} = 2 \pi f C_{\bullet} l \left(\frac{d e}{d x} \right)$$
 (17d)

The value of $\left(\frac{d e}{d x}\right)$ must be taken from equation of initial voltage distribution.

Case I.— Neutral Isolated. By equation (15b) at x = l

$$\frac{de}{dx} = \alpha \frac{E}{l} \tanh \alpha \tag{18a}$$

and
$$I = 2 \pi f C_{\bullet} \times \alpha \frac{E}{l} \tanh \alpha$$
 (18b)

Substituting (18b) in (17b).

$$C_{eff}$$
. = $\sqrt{C_o C_o} \times \tanh \alpha$, neutral isolated (19)

Case II.—Neutral Grounded. Solving similarly for the above case, but using equation (16b) instead of (15b),

$$C_{eff} = \sqrt{C_{\varrho} C_{\varrho}} \coth \alpha \tag{20}$$

As stated before, for values of α greater than 3, which is the case with most transformers, tanh α equals one, coth α equals one, and

$$C_{eff} = \sqrt{C_{o} C_{o}} \tag{21}$$

whether the neutral is grounded or isolated.

TIME REQUIRED TO CHARGE THE CONDENSERS TO THE INITIAL VOLTAGE DISTRIBUTION

The time required to charge a condenser by an incoming wave is given by the following formula, modified from one given by G. Faccioli in G. E. Review, 1914, page 749.

$$t = 2.3 C_{eff} Z \log_{10} \left(\frac{100}{100 - \% E_0} \right) \text{ seconds.}$$
 (22)

 $C_{eff.}$ = Equivalent massed capacitance of the winding from line to neutral, calculated by formula, (19), (20), or (21).

Z =Surge impedance of the transmission line, and may be taken between 300 and 400.

 $\% E_0$ = The actual terminal voltage in per cent of the final terminal voltage.

As an example, we will calculate the time necessary to charge the capacitance of the transformer described above to 90 per cent of its final value.

> $C_{\rm e} = 9 \times 10^{-10} \, {\rm farads.}$ $C_{\rm e} = 9 \times 10^{-12} \, {\rm farads.}$ $C_{\rm eff.} = 9 \times 10^{-11} \, {\rm by formula} \, (21)$

Substituting this value of C_{eff} in (22) we obtain

$$t = 2.3 \times 9 \times 10^{-11} \times 300 \times \log_{10} \left(\frac{100}{100 - 90} \right)$$


 $= 6.2 \times 10^{-8}$ seconds, which is about one twenty millionth of a second. It is justifiable, then, to assume that the initial voltage distribution by the condensers takes place before the inductance can begin to draw any appreciable current.

Analysis of Transient Phenomena Following the Initial Voltage Distribution

Let $I_L = Current$ in the winding.

 I_{\bullet} = Current in the coil capacitance.

 I_a = Current in the ground capacitance (total).



The following relation will be evident from Fig. 18.

$$\frac{dI_{L}}{dx} + \frac{dI_{\bullet}}{dx} - \frac{dI_{\bullet}}{dx} = 0$$
 (23a)

Equation (23a) states that the increase in the currents in the winding and the internal capacitance (as we go towards the line end) is equal to the current contributed by the ground capacitance, which is evident from Fig. 18.

For reasons that will be seen later, we differentiate (23a) with respect to t, and obtain

$$\frac{d^2 I_L}{dxdt} + \frac{d^2 I_*}{dxdt} - \frac{d^2 I_{\sigma}}{dxdt} = 0$$
 (23b)

It will be noticed that equations (23a) and (23b) are true generally and are independent of what the initial or final voltage distributions may be.

Equation (23) involves three variables, I_{L} , I_{g} and I_{s} , and, before it can be solved, it must be expressed in one variable.

Since we are interested mostly in the voltages, we will express the variables in terms of voltages.

Let e = voltage to ground.

e. = voltage gradient (volts per inch of coil) in the winding.

 $= \frac{d e}{d x}$

N = Total turns (line to neutral)

 φ = Total flux linking any turn.

 φ_L = Leakage flux linking any turn.

 $\varphi_{\mathbf{M}}$ = Main flux linking the total coil.

 $B_{\rm L}$ = Leakage flux density at any point.

h =Effective length of leakage path.

L =Leakage inductance of coil.

(MLT) = Mean length of turn.

(For a complete list of symbols see the end of this paper.)

To Find the Relation Between I_{\bullet} and Voltage. The current I_{\bullet} in the capacitance between coils is equal to the capacitances per inch l C_{\bullet} times the rate of change of voltage per

inch $\left(\frac{d e_{\bullet}}{dt}\right)$.

$$I_{\bullet} = l C_{\bullet} \frac{d e_{\bullet}}{dt} = C_{\bullet} l \frac{d^{2} e}{dxdt}$$
 (24)

$$\frac{d^2 I_{\bullet}}{dxdt} = C_{\bullet} l \quad \frac{d^4 e}{dx^2 dt^2}$$
 (25)

Equation (25) can be directly substituted in equation (23b).

To Find the Relation Between I, and Voltage. The current density in the capacitance to ground is equal to capacitance to ground per inch of coil times the rate of change of voltage to ground.

$$\frac{d I_o}{d x} = \frac{C_o}{l} \frac{d e}{dt}$$
 (26)

and

$$\frac{d^2 I_o}{dxdt} = \frac{C_o}{l} \frac{d^2 e}{dt^2} \tag{27}$$

Equation (27) can be directly substituted in (23b).

To Find the Relation Between I_L and Voltage. The relation between the magnetizing current (I_L) and the voltage is somewhat more complicated than that of the capacitance currents and voltage, due to the mutual inductance between turns

and the presence of leakage and main fluxes. The connecting links between current and voltage to ground at any point x are current at x, ampere turns or magnetomotive force effective in producing leakage flux, flux density at point x, flux producing voltage at point x, volts per turn and volts. See Fig. 19. The mathematical relation between these physical quantities are as follows:

The voltage gradient e_* , i. e., volts per inch, equals number of turns per inch N/l times the rate of change of total flux φ (= main flux φ_m + leakage flux φ_L). Thus,

$$e_{\bullet} = \frac{N}{l} \frac{d \varphi}{dt} 10^{-2} \tag{28a}$$

$$= \frac{N}{l} 10^{-6} \frac{d}{dt} \left\{ \varphi_{L} + \varphi_{m} \right\}$$
 (28b)

The leakage flux (φ_L) linking x is obtained by integrating the leakage flux density (B_L) . Thus,

$$e_{\bullet} = \frac{N}{l} 10^{-\theta} \frac{d}{dt} \left\{ (MLT) \int_{x}^{l} B_{L} dx + \varphi_{m} \right\}$$
 (28c)

If we differentiate (28c) with respect to x we get rid of the integral sign, and also of the last term because it is independent of x. Thus,

$$\frac{d e_{\epsilon}}{d x} = -\frac{N}{l} 10^{-6} (MLT) \frac{d B_{L}}{dt}$$
 (29a)

The negative sign in (29a) is due to x being the negative limit of integration in (28c). Of course it could have been assumed of the opposite sign provided other signs were kept consistent with it.

The leakage flux density B_L in (29a) is produced by the ampere turns enclosed by the flux.

$$B_{L} = \frac{N \mu}{l h} \int_{0}^{x} I_{L} dx \qquad (29b)$$

where $\mu = 4 - \frac{\pi}{10}$ when using dimensions in cm.

= 3.2, when using dimensions in inches.

h = effective length of leakage path.

It may be questioned why in (28c) we use the limits \int_{x}^{t} and

in (29b) \int_{0}^{x} . The reason may be stated thus; the flux link-




FIG. 19—NATURAL OSCILLATION WITHIN TRANSFORMER WINDING FOR 3/4 WAVE LENGTH
WITH ISOLATED NEUTRAL AND LINE END
CONNECTED TO TRANSMISSION LINE

The state of the

Curve 1, Volts to ground = E. Curve 2, Volts per turn are all the ampere = D E/D X. Curve 3, Flux density, or Magnetomotive turns from 0 to x. force = $D^2 E/D X^2$. Curve 4, Current = $D^3 E/D X^3$.

ing a current is outside of it, and the ampere turns producing the flux are inside of it. Therefore, if the total flux linking a certain point be integrated on the right of that point, the ampere turns producing that flux must be integrated on the left of the point. As a concrete example consider Fig. 19.

The flux producing voltage in a turn at the point x is all the flux from x to l; but the ampere turns producing the flux at x are all the ampere turns from 0 to x.

Returning to the

main problem, (29b) substituted in (29a) gives

$$\frac{d e_{*}}{d x} = - \frac{3.2 N^{2} (MLT)}{l^{2} h 10^{8}} \frac{d}{d t} \int_{0}^{x} I_{L} d x \qquad (29c)$$

$$= \frac{L}{l^3} \frac{d}{dt} \int_{-L}^{x} I_L dx \qquad (29d)$$

where

$$L = \frac{3.2 l N^2 (MLT)}{h 10^8}$$
 (See note opposite) (29e)

Differentiating (29d) with respect to x eliminates the integral sign. Thus,

$$\frac{d^2 e_{\bullet}}{d x^2} = -\frac{L}{l^3} \cdot \frac{d I_{\perp}}{dt}$$
 (30a)

Remembering that e_* (voltage gradient) is equal to $\frac{d e}{d x}$ (derivative of voltage to ground), (30a) becomes

$$\frac{d^3 e}{d x^3} = \frac{L}{l^3} \frac{d I_L}{dt}$$
 (30b)

(30b) gives the value of $\frac{dI_L}{dt}$, while, equation (23a)

involves $\frac{-d\ I_{\text{\tiny L}}}{d\ x}$. If we differentiate the former with respect

to x and the latter with respect to t, substitution becomes possible. This is the reason why (23a) was differentiated with respect to time giving (23b).

Differentiating (30b) with respect to x and rearranging.

$$\frac{d^2 I_L}{dxdt} = \frac{-l^3}{L} \frac{d^4 e}{dx^4} \tag{31}$$

(31), (25) and (27) express in terms of voltage the three terms of the fundamental differential equation (23b). Making the substitution, (23b) becomes

Note:—In discussing the leakage flux relations, we have assumed the effective length of the path as constant and independent of wave length. This is approximately true for only short waves on disk coils when the radial build of the coils is comparable to the wave length. Otherwise, the formula for L will not be accurate enough for numerical calculations. L, however, can be determined experimentally for various wave lengths as follows. Take one portion of the winding equal to one quarter of the wave length under consideration and short-circuit it. Take an equal portion adjacent to it, excite it as primary, and measure its inductance (= Reactance/377 for 60-cycle test). Multiply this value of inductance by $32 n^3$ to get the effective value of L for that wave length.

If the winding consists of disk coils, for approximate calculations the effective length of leakage path may arbitrarily be assumed as equal to the radial coil-build plus one-sixth of wave length:

$$h = b + \frac{l}{6n} \tag{29f}$$

$$\frac{d^4 e}{d x^4} - \frac{L C_s d^4 e}{l^2 d x^2 d t^2} + \frac{L C_s d^2 e}{l^4 d t^2} = 0$$
 (32)

(32) is the general differential equation of electrical phenomena occurring in windings, except that it does not take into account resistance and dielectric losses.

A solution of this equation is


$$e = A \cos p x \cos \omega t. \tag{33}$$


Substituting in equation (32) gives

$$\omega = \pm \frac{p^2 l^2}{\sqrt{L \left(\overline{C}_g + l^2 p^2 C_s\right)}}$$
 (34)

These equations show that a transformer is capable of sinusoidal oscillations in space and time at various frequencies and wave lengths.

Determination of the Constants. The voltage distribution may be expressed as the sum of a transient and a permanent





component. The permanent component is the final voltage distribution. For a d-c. voltage applied, the final voltage distribution is NB (Fig. 20) for the case of neutral isolated, that is, the whole coil assumes the impressed voltage E_0 against ground. The actual initial voltage being given by the hyperbolic curve OAB, the transient component is the difference between NB and OAB. Expressing the same relation in another way OAB represents the actual voltage when referred to OB as the axis of reference, but represents the transient component when referred to NB (the line of equilibrium) as the axis of reference. For neutral grounded (Fig. 21) OB represents the permanent or equilibrium line, and OAB (referred to OB as axis) represents the transient component of the voltage distribution.

To try to substitute the hyperbolic formula of initial voltage distribution in equation (33) leads to an indeterminate form,

but if analyzed into space harmonics (with respect to the line of final voltage distribution), substitution is readily effected, and the actual voltage to ground is the sum of the harmonics and the voltage of the reference line to ground.

An inspection of Fig. 5 shows that for neutral isolated the initial voltage distribution curve OAB is a quarter wave length (and its odd harmonics) with respect to the equilibrium line NB with maximum voltage at the neutral. An inspection of Fig. 6 shows that for neutral grounded the initial voltage distribution curve OAB is a half wave length (and its even and odd harmonics). The numerical values of the harmonics are derived by harmonic analysis.

Representing wave length by λ , initially, for neutral isolated,

$$e' = E_{\lambda} \cos \frac{2 \pi x}{\lambda} \tag{35}$$

and for neutral grounded

$$e' = E_{\lambda} \sin \frac{2 \pi x}{\lambda}$$
 (35a)

where $E \lambda$ is the maximum value of the wave.

The value of p in equation (34b) is therefore $\frac{2 \pi x}{\lambda}$ and

$$\omega = \pm \frac{4 \pi^2 l^2}{\lambda^2 \sqrt{L\left(\frac{C_g + 4 \pi^2 l^2 C_s}{\lambda^2}\right)}}$$
 (35b)

$$= \pm \frac{4 \pi^2 (l/\lambda)^2}{\sqrt{L \{ C_g + 4 \pi^2 C_s (l/\lambda)^2 \}}}$$
 (35c)

Now l/λ is the ratio of coil length to wave length and we shall designate it by small n. The longest wave to which the winding will oscillate is a quarter wave length, and n=1/4. Thus n may be looked upon as the order of the space harmonic. If n equals one, the wave length equals the coil length; if n equals two, the wave length is one:half of the coil length, or, there are two complete wave lengths from line to neutral. Substituting n for l/λ ,

$$\omega = \frac{4 \pi^2 n^2}{\sqrt{L (C_g + 4 \pi^2 n^2 C_*)}}$$
 (35d)

$$f = \frac{2 \pi n^2}{\sqrt{L (C_g + 4 \pi^2 n^2 C_s)}}$$
 (35e)

For long wave lengths (low harmonics, n small) capacitance to ground predominates,

and

$$f = \frac{2 \pi n^2}{\sqrt{L C_a}} \tag{35f}$$

For the very short wave lengths (high order of harmonics, n large) the coil capacitance C_n predominates.

$$f = \frac{n}{\sqrt{L C_*}} \tag{35g}$$

Since there are two values of ω , one positive and the other negative, and since $\cos (+\omega)$ equals $\cos (-\omega)$ equation (33) becomes

$$e' = A \cos (2 \pi n x/l) \cos (\omega_n t) + B \cos (2 \pi n x/l) \cos (-\omega_n t)$$
(33a)

=
$$A \cos (2 \pi n x/l) \cos \omega_n t + B \cos (2 \pi n x/l) \cos \omega_n t$$
 (33b)

$$= (A+B)\cos(2\pi n x/l)\cos\omega_n t \tag{33c}$$

$$= E_n \cos (2 \pi n x/l) \cos \omega_n t \tag{33d}$$

e' is the voltage to the axis of oscillation, and for every harmonic there is a term like (33d). The voltage to ground is, for neutral isolated,

$$e = E_0 - E_n \cos(2 \pi n x/l) \cos \omega_n t \qquad (33e)$$

and for neutral grounded

$$e = E_0(x/l) - E_n \sin(2 \pi n x/l) \cos \omega_n t \qquad (33f)$$

As the voltage oscillates above and below the line of equilibrium, and as the frequency is different for the different waves, we may assume that at some instant the maxima of all the harmonics at a point will add arithmetically, and that will represent the maximum voltage to ground at that point. That is, maximum voltage to ground equals, for neutral isolated.

$$\max e = E_0 + E_n \cos (2 \pi n x/l) + \dots$$
 (36a)

and for neutral grounded

$$\max e = E_0(x/l) + E_n \sin (2 \pi n x/l) + \dots$$
 (36b)

Of equal importance is the voltage gradient (volts per turn). The maximum voltage gradient at a point occurs when maximum voltage gradients of the various harmonics at that point add directly. This gives, for neutral isolated,

$$\max \frac{d e}{d x} = (2 \pi n/l) E_n \sin (2 \pi n x/l) + \dots$$
 (37a)

and for neutral grounded

$$\max \frac{d e}{d x} = E_0/l + (2 \pi n/l) E_n \cos (2 \pi n x/l) + \dots (37b)$$

It is to be noted that although the higher harmonics may be small in magnitude yet the volts per turn which they produce may not be negligible on account of the volts per turn varying directly with the order of the harmonic. For instance, a tenth harmonic having a magnitude of ten per cent of the fundamental will cause as much strain per turn as the fundamental.

The initial voltage gradient was discussed under equations (14,) (15) and (16).

SURGE IMPEDANCE OF A WINDING

The surge impedance of a transformer winding may be defined as the ratio of voltage impressed to current at line end of winding.

By equation (23)

$$\frac{d I_{L}}{d x} = \frac{d I_{e}}{d x} - \frac{d I_{e}}{d x}$$

$$= \frac{C_{o} d e}{l d t} - l C_{e} \frac{d^{2} e}{d x d t}$$

Substituting the general value of e, that is, $e = E \cos p x \cos \omega t$

$$\frac{d I_{L}}{d x} = -\omega E (C_{g}/l + l C_{s} p^{2}) \cos p x \sin \omega t$$

and integrating

$$I_{L} = \frac{\omega E}{p} (C_{g}/l + l C_{\bullet} p^{2}) \sin p x \sin \omega t \qquad (38a)$$

At the line end, $\sin p l$ equals one, and the maximum of the current occurs when $\sin w t$ equals one.

$$\max I_{L} = \frac{wE}{p} (C_{s}/l + l p^{2}C_{s})$$
 (38b)

$$Z = \frac{E}{I_1} = \frac{p \, l}{\omega \, (C_a + l^2 \, p^2 \, C_s)} \tag{39a}$$

$$Z = \frac{1}{2 \pi n} \times \sqrt{\frac{L}{C_s + 4 \pi^2 n^2 C_s}}$$
 (39b)

It is, therefore, evident that the surge impedance of a winding is not a constant but a function of the wave length, the shorter the wave length the less the surge impedance and hence, for a given voltage the current associated with higher harmonics is greater.

The current surges back and forth into the line, and it is assumed that the surge impedance of the line is low enough not to impede this free oscillation as will be seen in the following example.

EXAMPLE

The constants of the high-voltage winding of the above mentioned transformer are as follows,

$$C_{\bullet} = 9 \times 10^{-10}$$
 farads
 $C_{\bullet} = 9 \times 10^{-12}$ farads
 $\alpha = 10$

By formula (29e)

$$L = 8 \text{ for } n = 1/4$$

 $= 14 \text{ " } n = 1/2$
 $= 20 \text{ " } n = 3/4$
 $= 23 \text{ " } n = 1$
 $= 27 \text{ " } n = 5/4$
 $= 30 \text{ " } n = 3/2$
 $= 32 \text{ " } n = 7/4$
 $= 34 \text{ " } n = 4/2$

The initial voltage distribution is, by equations (11b) and (13b).

$$\% e = \frac{e}{E_0} = \frac{\cosh (10 x/l)}{\cosh (10)}$$
 neutral isolated
$$= \frac{\sinh (10 x/l)}{\sinh (10)}$$
 neutral grounded

These are plotted in Figs. 2 and 3 together with curves for other values of α .

Analyzing the curve for $\alpha = 10$ into its space harmonics with respect to the corresponding axis of oscillation, we find the following values:

Neutral Isolated.—

	Number		Voltage	
Order of harmonic	of wave lengths	$\frac{E n}{E_0}$		
Fundamental	1/4	_	125 %	
3nd	3/4	+	34 %	
5th	5/4	_	15 %	
7th	7/4	+	7 %	
9th	9/4	_	3.5%	
11th	11/4	+	1 %	

The frequencies corresponding to these harmonics, calculated by equation (35e), are

Order of harmonics

	n	λ	ω	f	Ratio
Fundamental	1/4	168 in.	28,000	4,600	1
3rd		56 "	150,000	24,000	5.2
5th		34 "	310,000	49,000	10.6
7th	7/4	24 "	480,000	76,000	16.5

Expressing the voltage to ground in per cent of line voltage (line to ground) the complete equation is

$$\% e = \frac{e}{E_0} = 1 - 1.25 \cos\left(\frac{\pi}{2} \times \frac{x}{l}\right) \cos 28,000 t$$

$$+ 0.34 \cos\left(\frac{3\pi}{2} \times \frac{x}{l}\right) \cos 150,000 t$$

$$- 0.15 \cos\left(\frac{5\pi}{2} \times \frac{x}{l}\right) \cos 310,000 t$$

$$+ 0.07 \cos\left(\frac{7\pi}{2} \times \frac{x}{l}\right) \cos 480,000 t \text{ etc.}$$

The maximum possible voltage to ground at any point at any time is equal to

max.
$$\% e = 1 + 1.25 \cos\left(\frac{\pi}{2} \times \frac{x}{l}\right)$$

 $+ 0.34 \cos\left(\frac{3\pi}{2} \times \frac{x}{l}\right)$

$$+ 0.15 \cos \left(\frac{5 \pi}{2} \times \frac{x}{l}\right)$$

 $+ 0.07 \cos \left(\frac{7 \pi}{2} \times \frac{x}{l}\right) \text{ etc.}$

This is plotted in Fig. 6.

The maximum voltage gradient is the derivative of the above equation.

max.
$$\% e_s = \frac{d e}{d x} = \frac{\pi}{2 l} \times 1.25 \sin \left(\frac{\pi x}{2 l}\right)$$

$$+ \frac{3 \pi}{2 l} \times 0.34 \sin \left(\frac{3 \pi x}{2 l}\right)$$

$$+ \frac{5 \pi}{2 l} \times 0.15 \sin \left(\frac{5 \pi x}{2 l}\right)$$

$$+ \frac{7 \pi}{2 l} \times 0.07 \sin \left(\frac{7 \pi x}{2 l}\right) \text{ etc.}$$

This is also plotted in Fig. 6. Calculating the voltage gradient at the line end by this formula we find that it is less than that obtained by equation (15b). This means that a sufficient number of harmonics are not included in the above formula. Neglecting the highest harmonics is permissible for the interior of the coil as they may be damped out before the highest possible maximum would be reached, but for the line end it is better to calculate the voltage gradient by the hyperbolic formula. This has been done in the calculation of the above curve.

Neutral Grounded. The initial voltage distribution for this case is practically the same as for isolated neutral (see Fig. 3, $\alpha = 10$). Analyzing this curve into space harmonics with respect to the slant line $\alpha = 0$, we find the following values:

No. of wave lengths on the

stack	E z	6.9		Ratio
*	E_0	ω	J	TOTAL O
1/2 -	58	84,000	13,000	1
$2 \times \frac{1}{2}$ -	+ .23	230,000	37,000	2.8
$3 \times \frac{1}{2}$	13	390,000	62,000	4.8
$4 \times \frac{1}{2}$	06	580,000	92,000	7.1

The maximum voltage to ground is

max. % e

$$= \frac{x}{l} + 0.58 \sin\left(\frac{\pi x}{l}\right) + 0.23 \sin\left(\frac{2\pi x}{l}\right)$$
$$+ 0.13 \sin\left(\frac{3\pi x}{l}\right) + 0.06 \sin\left(\frac{4\pi x}{l}\right) \text{ etc.}$$

This is plotted in Fig. 7.

The maximum voltage gradient is the derivative of the above.

max.
$$\% e_s = \frac{d e}{d x} = \frac{1}{l} + \frac{0.58 \pi}{l} \cos\left(\frac{\pi x}{l}\right)$$

$$+ 0.23 \times \frac{2 \pi}{l} \cos\left(\frac{2 \pi x}{l}\right)$$

$$+ 0.13 \times \frac{3 \pi}{l} \cos\left(\frac{3 \pi x}{l}\right)$$

$$+ 0.06 \times \frac{4 \pi}{l} \cos\left(\frac{4 \pi x}{l}\right) \text{ etc.}$$

This also is plotted in Fig. 7.

Surge Impedance. By equation (39b)

$$n = 1/4$$
 $1/2$ $3/4$ 1 $11/4$ $11/2$ $13/4$ 2 $Z = 60,000$ $38,000$ $29,000$ $22,000$ $17,000$ $14,000$ $11,500$ $9,600$

Symbols

 $\alpha = \sqrt{C_{o}/C_{s}}$

A = Constant of integration

B = Flux density, also constant of integration.

C = Capacitance.

 C_o = Capacitance to ground (total.)

 C_{\bullet} = Coil capacitance (total), from line end to neutral.

 E_0 = Terminal voltage, i. e., line to ground.

 $E_n = \text{Max.}$ value of the "n" th harmonic to the axis of oscillation.

e = Voltage to ground at any point at any instant.

e. = Voltage gradient in the winding, volts per unit length, proportional to volts per turn.

f = Frequency cycles per second, $\omega/2 \pi$.

g = Subscript meaning ground.

I = Current.

l =Length of coil (or coil stack), line to neutral.

N =Number of turns total, line to neutral.

n = Number of wave lengths on the winding for a given harmonic.

 ω = Angular velocity, radians per second.

 $= 2 \pi f$

Z = Surge impedance.

DISCUSSION ON "ABNORMAL VOLTAGES WITHIN TRANSFORMERS" (BLUME AND BOYAJIAN), NEW YORK, N. Y., FEBRUARY 21, 1919.

H. R. Summerhayes: I would like to have the author give some additional information on the value of alpha, it goes over one per cent; now, it has occurred to me that in some classes of apparatus, for instance, as induction regulators or in generator coils, that alpha might be less than one, I may be wrong, but it is even conceivable that if the iron is brought close to all of the coils as in a generator or as in a transformer which might have ground shields between the coils, that the value of alpha might be less than one. I would like to know how that would modify the conclusions.

I am interested to notice the difference between grounded neutral systems and those with isolated neutral. Apparently, in most cases the grounded neutral has some advantage in the effect on the apparatus, especially with rectangular

waves.

- G. Faccioli: I knew by experience and theory that transformer coils—like men—do not always cooperate, so that when an abnormal condition of operation arises some of the coils are left to take the brunt of the disturbance while other coils do not do their share. I also knew, as all the engineers interested in this class of phenomena knew, that the capacity of the transformer winding is the controlling factor of the distribution of voltage when a steep wave front impinges upon the winding but I did not know the definite law governing the relation between the distribution of voltage and the capacity. Now Lord Kelvin said that you never know a phenomenon until you can put it into figures. The authors of this paper have succeeded for the first time in putting this phenomenon into figures and therefore I feel that they have for the first time really explained it, rendering thereby a great service to the art.
- C. A. Adams: I feel that we owe a debt of gratitude to those men who are willing to devote their valuable time to the preparation of papers of this kind. Such papers are not popular, and are frequently criticized by many who attend our meetings, but they are of the utmost fundamental and practical importance and constitute the foundation on which the practical designing engineer must build if he is to be sure of his superstructure.

Referring now to this particular subject, we all realize that the mathematical analysis is approximate. It is impossible to state in accurate mathematical terms the complete physical problems, as the conditions are too complex, but when the mathematical analyses have been made as carefully as we know how under the circumstances, and when the conclusions have been checked by careful research work, they become tremendously useful in rationalizing our attack on

the practical problem in hand, and in dealing with new problems in the same field.

H. R. Summerhayes: It seems to me that the paper has a bearing possibly upon testing, I think the author mentioned that it might be possible to build transformers in accordance with these principles, which would be strong for the service and cheap, so to speak, but would not necessarily meet the present rules of testing, and I think that is where the paper has important bearing in its possible effect on the rules.

C. A. Adams: You refer to the Standardization Rules? H. R. Summerhayes: Yes, the rules for insulation testing.

C. A. Adams: That is certainly a very important bearing. J. F. Peters: (Abstracted by L. W. Chubb.) It has been known for many years that during disturbances high voltages are developed in transformer windings and especially in that part of the winding adjacent to the line. The paper is of considerable value and interest because it affords a method of approximately determining the magnitude and distribution

of these abnormal voltages under certain conditions.

The authors have computed and plotted in Figs. 2 and 3 the voltage distribution in a transformer winding for various values of α when a voltage having a sheer front or rectangular wave is suddenly applied to the terminals. By an exactly similar method the voltage distribution in any coil of the stack can be determined. The authors have taken as a unit, one coil length. Now, if we consider one coil and take as a unit, one turn, and consider X along the plane of the coil (at right angles to the length of the stack) then the solution for the coil is the same as for the stack with grounded neutral. C_{σ} becomes the capacitance between the coil under consideration and the next adjacent coil and C_{σ} becomes the capacitance between the inner and outer turns of the coil. The voltage distribution within the coil

$$e' = E_0' \frac{\sinh \frac{a' x'}{l'}}{\sinh a'} \qquad a' = \sqrt{\frac{C_{\sigma'}}{C_{\bullet'}}}$$

 E_{0}' = voltage across the coil considered.

e' = voltage distribution in coil.

a' is always greater than zero and in many cases may be greater than a.

Therefore, the maximum voltage per turn may be considerably greater than that given by the slope of the curves in Fig. 2 and 3. In insulating the windings for these abnormal voltages between turns and between coils one has, as in the design of most apparatus, the choice of two evils. The voltage for any coil of the stack is approximately constant irrespective of the number of turns it contains. Therefore, decreasing the

number of turns in the line coil in order to get more space for insulation increases the voltage per turn of the coil and one must choose between volts per turn and insulation space between turns.

The information that the paper gives on the effect of grounding the neutral is very interesting. For the example that the authors have computed, the maximum voltage to ground for grounded neutral is 1.5 normal as compared with 2.8 times for isolated neutral. The voltage per turn for the major part of the winding is approximately the same for both. It is four times normal for the isolated connection and five times normal for the grounded connection. The voltage per turn for the line end of the stack is the same for both connections, while for the neutral end, the voltage per turn is greater for the grounded connection, but is less than the volts per turn at the line end. Both ends of the stack are generally insulated the same for reasons of symmetry; therefore there is no additional difficulty encountered in the end turn insulation for the grounded neutral and there is a decided gain in the maximum voltage to ground.

I feel that the conclusions drawn regarding the transient voltage distribution following the initial voltage are not entirely fair. Equations (33e) and (33f) give these transients only when the damping factors due to resistance and dielectric losses are neglected. When including the damping factors the parts of these equations that are multiplied by E_n are also multiplied by the damping factors. For the high frequencies in these transients the damping is undoubtedly large and by the time all the harmonics have simultaneous maximums the damping factors will have gotten in their good work on decreasing the amplitudes and it is questionable whether the assumptions leading to equations (36a) and (36b) are justified.

F. Dubsky: The factor alpha for alternator, motor and induction regulator windings, having coils embedded in slots, may be estimated with the following values:

For one single coil $\alpha = 0.7$ to 2 (the larger value for deep and narrow slots).

For one phase of the winding $\alpha = (0.7 \text{ to } 2)$ times the number of coils connected in series per phase.

Since the factor alpha for one coil is comparatively small it follows that the voltage distribution within a coil can be considered as uniform.

The factor alpha per phase may attain, of course, a considerably large value and produce, therefore, a greater concentration of voltage across the line coil.

Since all coils of the alternator, motor and induction regulator windings are usually wound and insulated alike, their layer and turn insulation should be selected in proper relation to the coil insulation to ground.

F. W. Peek, Jr.: The effects of sustained high-frequency oscillations have been mentioned. Some time ago we

made extensive experiments with sustained high-frequency oscillations impressed on transformers. Voltages were measured over a wide range of impressed frequencies by gaps placed across taps brought out from the various coils throughout the winding.

It was found that voltages equivalent to line voltage could be built up across a very small fraction of the winding. The point or points of maximum voltage occurred at different parts of the winding, depending upon the frequency of the applied oscillations. These high internal voltages existed without appreciable increase in voltage across the terminals. A gap arrester is thus not effective for protection against these oscillations. Protection may be obtained, however, by shunting the apparatus by a condenser and resistance in series.

These data are of great importance, in design, to determine the best methods of applying insulation and of building transformers as free from the probability of high internal voltages as possible. Mr. Blume's paper is of importance from both

of these standpoints.

Fortunately, there need be but very little fear of conditions producing high internal voltages on a properly insulated, connected, and operated system.

A. E. Kennelly: (communicated after adjournment). The paper is of special interest from the standpoint of artificial electric lines. It brings to our notice a new type of artificial line, and one which deserves consideration from the operating engineer. This new type is an all-capacitance line, with its series elements shunted by inductances. The conditions, however, are such that at the moment of initial disturbance, the inductance shunts are virtually non-existent, by reason of their sluggishness of action; so that the artificial line presented in a high-tension transformer is at first, very nearly a pure all-capacitance line. After the lapse of a certain brief period, the inductance shunts begin to come into play. The artificial line thereafter changes to one of mixed character, with condensers and inductances in series, and condensers in shunt. It is this automatic change in the nature of the artificial line of the transformer with time, that makes the case presented in the paper so interesting.

The theory of all-capacitance artificial lines has been already outlined.* It has been shown that in any pure all-capacitance line, the potential and current distributions are independent of the frequency, and belong to the hyperbolic-sine and hyperbolic-cosine series of numbers, whether the distant end be grounded or freed. From this point of view, the quantity α , defined on the second page of the paper, is the angle subtended by the line, uncorrected for lumpiness, is a real angle expressible in hyperbolic radians, and is the same at all frequencies.

^{*} Artificial Electric Lines, by A. E. Kennelly, New York 1917, Chapter XVII.



The quantity described in (21) as the effective capacitance of the transformer, is the surge admittance of the line, when multipled by $j\omega$, where ω is the impressed angular velocity. Again the quantity defined as $\alpha X/l$, in (11) and (13), is the position angle of a point on the line. Equations (13) and (14) merely restate the well known propositions that the potential and current at any point on an artificial line are respectively proportional to the sine and cosine of the position angle at the point. It is to be noted that a value for α such as 10, given in the paper, is a very large real hyperbolic angle. It shows that such transformers may develop large angles, and that alternating-current artificial lines may present real angles, whereas it is very commonly supposed that all such lines develop complex angles varying with the frequency.

No oscillations are possible in a homologous line; of which an all-capacitance line is one type; because the energy is all of one type—in this case electric energy—and the energy must be capable of appearing in more than one type—such as either electric or magnetic energy—in order that oscillations may occur. When the inductance shunts are awakened, and come into action, the oscillations discussed in the paper begin to

appear.

It will be of very great interest, and also of great practical importance, to ascertain how long it takes to wake up the inductance shunts, and how gradual the awakening is. It is to be hoped that the authors will attempt to answer these

questions experimentally.

L. F. Blume: In reply to Mr. Summerhayes' question regarding the value of alpha (ratio of ground capacitance to series capacitance) this design constant in practise may vary from values approaching zero to very high values. It is possible to have values less than one where the ground capacitance is small compared with series capacitance. However, I doubt if this condition occurs very often in practise. In apparatus other than transformers in the majority of cases, the value of alpha is quite large. In the case of a transmission line the value of alpha is infinity because series capacitance is zero.

Mr. Peters raises the question concerning the initial distribution of potential within a coil. In the type of transformer winding analyzed in our paper, the value of internal capacitance (capacitance from layer to layer) is relatively large, that is, large compared with capacitance from edge of coil to ground, due to the small distance between layers. And since this capacitance is essentially in series with ground capacitance, it can have but little effect on the voltage distribution to ground, and between layers within the coil. However this is not necessarily true for all types of windings and for this reason, it is important that the distribution within the coil should be properly analyzed.

The influence of internal losses on oscillations is undoubtedly



of very great practical importance because the insulation and other losses combined, very quickly absorb the energy of oscillation. It should be remembered in this connection that only a small fraction of energy of an impinging wave enters a transformer winding, the majority being returned to the transmission line by reflection. To take care of the energy losses in the theory would have made the mathematics very much more involved. We have only attempted to outline in a rough way the influence of losses in dampening out these oscillations.